



# Dynaudio 18S

## Firmware update instructions

## DYNAUDIO

Dynaudio A/S  
Sverigesvej 15  
DK-8660 Skanderborg  
T: +45 8652 3411  
dynaudio.com

## Requirements

- Empty USB stick. Formatted to FAT32.
- The latest firmware downloaded from <http://www.dynaudio.com/support/firmware/>

## Steps

1. Unzip the downloaded Zip file.
2. Copy the 'DYNAUDIO.bin' firmware file into the root directory of the USB stick.
3. Switch OFF the loudspeaker with the rear-panel switch.
4. Insert the USB stick into the USB port at the rear panel labeled 'Service'.
5. Switch ON the loudspeaker with the rear-panel switch.
6. Your subwoofer will automatically download the firmware from the USB stick.
7. After this, let the sub install the full update, which should take 1-3 minutes. DON'T TURN IT OFF.
8. During this update the LED will change from red to blue and display various messages about the update progress.
9. After installation is complete, the LED will turn green and the display will return the message: Update result - Success!
10. Your firmware update procedure is now finished. Switch OFF the loudspeaker and remove the USB stick.
11. Switch ON the subwoofer.
12. Check the firmware version in the menu info screen.